

## Line extension LVM 100



For additional connection of up to 4 loop or 8 stub lines

UEZ 2000: Can be expanded with 1 LVM UEZ 2000/6: Can be expanded with 1 LVM

UEZ 2000/1: Cannot be expanded.

## **Ordering Information**

Line extension LVM 100 LVM 100 Additional connection of max. 4 loop or 8 stub lines, UEZ 2000, UEZ 2000/6 can be expanded with 1 LVM