




SIV 28 V Fuse distributor



For monitored fusing of units connected to BZ 500 /
UEZ 2000, max. 5 fuses.

Ordering Information

SIV 28 V Fuse distributor SIV 28
Fusing for units connected to BZ 500/UEZ 2000,
max. 5 fuses